

LI2208 WinPOS: Programming Barcodes for LI2208

Configuration name in Utility : LI2208 WinPOS
Last Modified : 15-Nov-18
Windows Filename : Config File_LI2208_
Plug-in Name : WinPOS_EANEXTNDOFF.scncfg
LI2208-STANDARD SR MODELS-013



Instructions: Scan barcodes in order, starting with programming barcode 1.

1/10. Set Factory Defaults



Cable Connection Settings

USB

2/10. USB Device Type Default (HID Keyboard Emulation),Ignore Beep Directives Enable



3/10. Ignore Type Directives Enable,Emulate Keypad Disable



4/10. Quick Keypad Emulation Disable,USB Polling Interval 8 msec



Symbology (bar code type) Settings

5/10. Enable UPC-E1,Decode UPC/EAN/JAN Supplementals Autodiscriminate,UPC/EAN/JAN Supplemental Redundancy 7,Enable Convert UPC-E to UPC-A



6/10. Enable Convert UPC-E1 to UPC-A,Enable EAN-8/JAN-8 Extend,ISBN-13 Bookland ISBN Format



LI2208 WinPOS: Programming Barcodes for LI2208

Configuration name in Utility : LI2208 WinPOS
Last Modified : 15-Nov-18
Windows Filename : Config File_LI2208_
Plug-in Name : WinPOS_EANEXTNDOFF.scncfg
LI2208-STANDARD SR MODELS-013



Modify Data

7/10. Suffix 1 Enter,7,0,1,3,Scan Data Transmission Format <Data><Suffix 1>



General Parameter Settings

8/10. Disable Low Power Mode,Timeout Between Same Symbols 6,Timeout Between Different Symbols 2,Decode Session Timeout 30



9/10. Beeper Volume Low,Beeper Tone Low



10/10. Configuration File LI2208 WinPOS



Firmware:

CAABWS00-001-R09

Supported Scanner Models for Plug-in :

LI2208-HC0000BZZWW

LI2208-SR00006ZZNA

LI2208-SR00006ZZWW

LI2208-SR00007ZZAY

LI2208-SR00007ZZNA

LI2208 WinPOS: Programming Barcodes for LI2208

Configuration name in Utility : LI2208 WinPOS
Last Modified : 15-Nov-18
Windows Filename : Config File_LI2208_
Plug-in Name : WinPOS_EANEXTNDOFF.scncfg
LI2208-STANDARD SR MODELS-013



LI2208-SR00007ZZWW

LI2208-SR7U2100AZY

LI2208-SR7U2100SGY