

# LS-1902T on Portable Register

The page numbers listed were accurate as of the time of this document, and may have changed since then.  
If they have changed, they will probably still get you to the right section of the Symbol book.



**SET ALL DEFAULTS**  
Page 5-7



**STANDARD RS-232C**  
Page 5-11



**CONVERT UPC-E TO UPC-A  
(ENABLE)**  
Page 5-31



**DECODE UPC/EAN WITH SUPPLEMENTALS**  
Page 5-26



**AUTODISCRIMINATE UPC/EAN SUPPLEMENTALS**  
Page 5-26



**SCAN SUFFIX**  
Page 5-75



**1**  
Page 5-95



**0**  
Page 5-95



**1**  
Page 5-95



**3**  
Page 5-95



**SCAN OPTIONS**  
Page 5-76



**<DATA> <SUFFIX>**  
Page 5-76



**ENTER**  
Page 5-77