

Modified: Programming Barcodes for LS2208

Configuration name in Utility : Modified
Last Modified : 12-Oct-18
Windows Filename : Config File_LS2208_Modified_2018.10.12.scncfg
Plug-in Name : LS2208-COMMON MODELS v2.0-007



Instructions: Scan barcodes in order, starting with programming barcode 1.

1/8. Set Factory Defaults



Cable Connection Settings

USB

2/8. USB Device Type Default (HID Keyboard Emulation),Ignore Beep Directives Enable



3/8. Ignore Bar Code Configuration Enable



Symbology (bar code type) Settings

4/8. Enable UPC-E1,Decode UPC/EAN/JAN Supplementals Autodiscriminate,Enable Convert UPC-E to UPC-A,Enable Convert UPC-E1 to UPC-A



5/8. Enable EAN-8/JAN-8 Extend,ISBN-13 Bookland ISBN Format



Modify Data

6/8. Suffix 1 Enter,7,0,1,3,Scan Data Transmission Format <Data><Suffix 1>



Modified: Programming Barcodes for LS2208

Configuration name in Utility : Modified
Last Modified : 12-Oct-18
Windows Filename : Config File_LS2208_Modified_2018.10.12.scncfg
Plug-in Name : LS2208-COMMON MODELS v2.0-007



General Parameter Settings

7/8. Beeper Volume Low,Beeper Tone Low



8/8. Configuration File Modified



Firmware:

CAACFS00-002-R00

Supported Scanner Models for Plug-in :

LS2208-SR20001BR

LS2208-SR20001BR-K

LS2208-SR20001BR-R

LS2208-SR20001BR-U

LS2208-SR20001BZ-K

LS2208-SR20001NA

LS2208-SR20001R

LS2208-SR20001R-KR

LS2208-SR20001R-NA

LS2208-SR20001R-UR

LS2208-SR20001Z-UR

LS2208-SR20007BR-K

LS2208-SR20007BR-R

Modified: Programming Barcodes for LS2208

Configuration name in Utility : Modified
Last Modified : 12-Oct-18
Windows Filename : Config File_LS2208_Modified_2018.10.12.scncfg
Plug-in Name : LS2208-COMMON MODELS v2.0-007



LS2208-SR20007BR-U

LS2208-SR20007BZ-K

LS2208-SR20007NA

LS2208-SR20007R

LS2208-SR20007R-KR

LS2208-SR20007R-NA

LS2208-SR20007R-UR

LS2208-SR20007Y

LS2208-SR30001R

LS2208-SR30007R