

**LS-2208 Connected via Synapse Connection to Keyboard on Register**  
(Scan top to bottom, first column first, second column next)



SET ALL DEFAULTS



IBM PC/AT and IBM PC COMPATIBLES



CONVERT UPC-E TO UPC-A  
(ENABLE)



DECODE UPC/EAN WITH SUPPLEMENTALS



AUTODISCRIMINATE UPC/EAN SUPPLEMENTALS



SCAN SUFFIX



1



0



1



3



SCAN OPTIONS



<DATA> <SUFFIX>



ENTER