

**SYMBOL DS9808
Using USB Connection
On WinPOS and PRISM POS**



***Set Defaults**



Convert UPC-E to UPC-A (Enable)




Decode UPC/EAN/JAN Only With Supplementals




Autodiscriminate UPC/EAN/JAN Supplementals



IBM PC/AT & IBM PC Compatibles



Scan Options



<DATA> <SUFFIX>



Enter